

S3600/5600系列交换机上查看STP历史状态变化的命令说明

岳斌 2008-06-25 发表

1、进入隐含模式：

```
<H3C>system-view
```

System View: return to User View with Ctrl+Z.

```
[H3C]_
```

Now you enter a hidden command view for developer's testing, some commands may affect operation by wrong use, please carefully use it with our engineer's direction.

```
[H3C-hidecmd]
```

2、输入显示STP历史状态变化的命令：

```
[H3C-hidecmd]_dis stp history unit 1
```

```
----- Stp Instance 0 history trace -----
```

内容略。

该命令在定位STP状态错误或者拓扑变化的问题时，非常有利于记录网络的历史变化。帮助我们准确快速定位STP相关问题。