



MSR Router NAT Process function Note

Q: What's NAT process mode of MSR Router?

A:

Router default using NAPT work method and require ICMP package, TCP package or UDP package. There is a defect of RAW IP package. Interface distribute NAT configuration, don't trigger NAT conversion. If configure NAT transfer mode IPSec at first, meanwhile MSR don't distribute NAT in network. Now if distribute NAT rule, you will find IPSec SA don't be deleted and IPSec data package don't be transferred by NAT. Thus IPSec data package don't have UDP header, which is RAW IP package. Now It is better to take into effect of Reset IKE SA and Reset IPSec SA.