

Configure loghost


Keywords: MSR ;loghost

1. Requirements:

The router sends its system logs to the loghost, and saves them in files on the loghost for reference at any time.

Device: MSR series router

2. Network diagram:



3. Configuration steps:

Device and version: MSR series、 version 5.20 and Beta 1106

RTA key configuration scripts

```
#
// Specify loopback0 as the source address sending the log information
info-center loghost source LoopBack0
// Configure the loghost
info-center loghost 192.168.0.100
#
//connect the loghost
interface Ethernet0/1
 port link-mode route
 ip address 192.168.0.1 255.255.255.0
#
//Configure loopback0 IP address
interface LoopBack0
 ip address 1.1.1.1 255.255.255.255
#
```