

知 What is ASM default management interface address?

纪合宝 2009-01-14 发表

What is ASM default management interface address?

**Q:** What is ASM default management interface address?

**A:**

The default ASM management address is 192.168.2.1