

知 How to modify ASM management address under command line mode?

纪合宝 2009-01-14 发表

How to modify ASM management address under command line mode?

Q: How to modify ASM management address under command line mode?

A:

Under command line mode, input:

```
[RsShell]$ ipadd eth1 add 1.1.1.1 255.255.255.0
```

1.1.1.1 is the configurable ASM management address.