

知 What's the system default sequence of voice entity and logical interface?

纪合宝 2009-01-14 发表

**What's the system default sequence of voice entity and logical interface?**

**Q: What's the system default sequence of voice entity and logical interface? Can it be configured?**

**A:**

The default sequence is from low to high. If E1 interface has 30 B channels, the first choice is 0, and the second choice is 1, you can configure using "isdn bch-select-way"