



How to configure VPM and VCPM module of MSR30xx?

纪合宝 2009-01-14 发表

How to configure VPM and VCPM module of MSR30xx?

Q: When MSR30xx has both SIC VE1 and MIM VE1, how to configure main card and MIM card? Do they need configure VPM and VCPM?

A:

If you use SIC digital voice card, you must use main card VCPM, otherwise VE1/VT1 can not run well.

If you don't configure VoIP, and VPM is not needed, otherwise, if you configured VoIP and VPM is mandatory.