

知 What's the function of Tunnel-on when H.323 quick starts?

纪合宝 2009-01-14 发表

What's the function of Tunnel-on when H.323 quick starts?

Q: What's the function of Tunnel-on when H.323 quick start?

A:

Tunnel-on environment:H.323 + Fast-connect + H.245 attached DTMF. H.323 quick start need configure H.245 attached DTMF, so must configure Tunnel-on to transfer 245 message encapsulated in 225. Tunnel-on default value is on, which can be configured at Voice-Setup in voip view. And the configuration of Tunnel-on must be consistent in incoming and outgoing call.