



## How to configure MSR hardware encrypted?

纪合宝 2009-01-14 发表

### How to configure MSR hardware encrypted?

**Q: How to configure hardware encrypted?**

**A:**

Set the corresponding policy and using it

```
[system]encrypt-card fast-switch
```

```
[encrypted view] IPsec binding policy policy-name
```