

纪合宝 2009-01-15 发表

How to display MSR device manuinfo?

Q: How to display MSR device manuinfo?

A:

Use the command: display device manuinfo